


# H-Z SERIES CENTRIFUGAL WATER PUMP



No.	Name	No.	Name
1	Rubber Plug	29	Mechanical seal
2	Screw	30	O-ring
3	Front cover plate	31	Backing plate
4	O-ring	32	Water baffle ring
5	Check valve seal ring	33	Connection
6	Check valve stem	34	Controller bracket
7	O-ring	35	Rotating shaft
8	Check valve seat	36	Rotor
9	Check valve spring	37	Bearing
10	Retaining ring	38	Wave washer
11	Pump body	39	Wound stator
12	Screw and gasket	40	Spring washer
13	Sensor	41	Screw
14	O-ring	42	Motor body
15	Outlet plug	43	Self-tapping screw
16	Pressure tank	44	Base plate
17	Hexagon nut	45	Screw
18	Washer	46	Shock absorber pad
19	Return guide vane seal ring	47	Flat washer
20	O-ring	48	Hexagonal bolt
21	Return guide vane	49	Wire pressing buckle
22	O-ring	50	Self-tapping screw
23	Guide vane cover plate	51	Inverter controller
24	Intermediate guide vane	52	Outgoing line plug
25	Plastic impeller	53	Fan
26	Final stage guide vane	54	Shaft retaining ring
27	Outlet guide vane	55	Rear cover plate
28	Shaft elastic retaining ring		